

ELECTRICAL LEGEND		
S.No.	SWITCH BOARD	HT. FRM FFL
1	TSB-01	3'-6"
	a. Switch for ceiling lights	
	b. Switch for exhaust	
	c. Switch for mirror light	
	d. One 15 amp socket with switch for hand dryer	
2	SB-01	3'-6"
	a. Switch for ceiling lights	
	b. One 15 amp socket with switch	
	c. Two Switches for raw points	
	d. One Switch for wall light	
	e. One Switch for cove lights	
	f. One Switch for AC	
3	FSB-01	ON FLOOR
	a. One 15 amp socket with switch	
	b. One 5 amp socket with switch	
	c. One Telephone point	
	d. Point for WIFI	
4	SBTV-01 (TV)	
	a. Two 5 amp sockets with switch	
	b. Switch for socket at SBTV 02	
5	SBTV-02 (TV)	4'-0"
	a. One 16 amp socket	Switch at SB-01
	b. One Television point	
6	WSB-01	3'-6"
	a. Switch for ceiling lights	
	b. One 5 amp socket with switch	
	c. One Switch for wall light	
	d. One Switch for cove lights	
	e. One Switch for AC	
7	PSB-01	3'-6"
	a. Switch for ceiling lights	
	b. One 5 amp socket with switch	
	c. Two Switches for wall lights	
8	RSB-01	3'-6"
	a. Two Switches for ceiling lights	
	b. Two 5 amp socket with switch	
	c. Two Switches for wall lights	
	d. Switch for sign-age light	
	e. Two Switches for AC	
9	SSB-01	3'-6"
	a. One Switch for ceiling lights	
	b. One 5 amp socket with switch	
	c. Two Switches for wall lights	
	d. One Switch with regulator for fan	
	e. One Switch for AC	
10	ASB-01	3'-6"
	a. Two Switches for ceiling lights	
	b. One 5 amp socket with switch	
	c. One 15 amp socket with switch	
	d. One Switch for raw points	
	e. One Switch for AC	

ELECTRICAL LEGEND		
1.		WALL LIGHT @ 7'-0"
2.		RAW POINT
3.		SWITCH BOARD
4.		AC @ 7'-6"
5.		CEILING EXHAUST

